



DIAMOBILE XL™

A COMPACT AND MOBILE SYSTEM FOR EVALUATING AND
PLANNING ROUGH DIAMONDS

COMPONENTS REVIEW & QUICK SETUP

by Sarin Technologies Ltd.


P/N 30-0002-16

Rev 1


Components Review

- DiaMobile XL system:
 - A. Main body
 - B. Systems connections
 - C. Power supply unit (AC / DC adapter + cable)
 - D. USB cable
- Carrying bag
- Hasp

Main body description




System's connections description



Power supply unit description



USB cable description



Carrying bag description



HASP description



Quick Setup

In order to start working with the DiaMobile XL (after software installation on PC)

1. Connect Power supply unit both to the machine and to the electricity
2. Open PC
3. Connect USB cable both to the machine and to the PC
4. Connect the HASP to the PC (without the HASP connected the applications will not run)
5. Open application (Advisor™ or DiaVision™)
6. The DiaMobile XL system is ready for work